

# How to Fit

## Perfect Fit Shutters

---

Using a credit card as a guide slot a bracket into the corner of each gasket seal on the window.



Once all brackets are in place the shutter is ready to be installed. Line the cut-out in the bottom of the frame with the bottom brackets.

Once the bottom of the frame is clipped in, push the top side of the frame into the top brackets. Your Perfect Fit Shutter is now installed!

