

How to fit your Perfect Fit® blind using the window fixing brackets

Apply lubricant in the form of washing up liquid to the flat base of the window fixing bracket prior to insertion of the bracket between window and rubber seal.

- 5 For the correct spacing distance of the brackets (85mm), place the credit card into a corner of the window.



- 6 Line up the window fixing bracket at the base of the card (or top of the card depending upon which corner of the window you are working) and fit the bracket by pushing it between the glass and the rubber seal on the window.



Need Help? Call us on **0845 652 1963**

How to fit your Perfect Fit® blind using the window fixing brackets (continued)

- 7 Using the credit card guarantees a perfect line up for each of the holes in your frame with each of the brackets



- 8 Fit any intermediate brackets accordingly. Clean excess lubricant from window surface prior to fixing frame to brackets.



Need Help? Call us on **0845 652 1963**

How to fit your Perfect Fit® blind using the window fixing brackets (continued)

- Take the Perfect Fit® frame and offer the left hand side to the left hand brackets. Align the frame holes with the bracket lugs. Click into place. Repeat this process for the right hand side. Now the Perfect Fit® frame is locked in position.

To remove the frame use a flat headed screwdriver and depress the bracket lugs while gently easing out the frame.

