


INSIDE RECESS

Using a steel tape measure, take a measurement across the width of the recess top, middle and bottom and jot down the smallest size. Do the same for the drop of the recess.

Watch out for obstructions such as tiles and dado rails.


Enter these sizes online and choose 'recess size' in the options. We will make all the necessary deductions for your blind to fit perfectly.



OUTSIDE RECESS

Using a steel tape measure, take a measurement across the width and the drop of the area you want the blind to cover.

Enter these sizes online and choose 'blind size' in the options. If you are measuring for a roller blind, you will need to choose 'cloth size'. For a standard roller blind your brackets will extend 35mm outside the cloth size.



MEASURING GUIDE

Our blinds can be installed **inside** or **outside** the recess. This measuring guide is suitable for the the following types of blinds:

- Vertical Blinds
- Roller Blinds
- Venetian Blinds

If you have any questions then drop us an email with photos of your window and we will advise you on the best available solutions.

 www.blind-land.co.uk

 01205 400115

 sales@blind-land.co.uk



Measuring Guide

for Vertical Blinds, Roller Blinds, Venetian Blinds,
Roman Blinds and (free hanging) Pleated Blinds



www.blind-land.co.uk



01205 400115



sales@blind-land.co.uk